

6-2. Owner's customize Customizable features

Your vehicle includes a variety of electronic features that can be personalized to your preferences. Programming these preferences requires specialized equipment and may be performed by an authorized Lexus dealership.

Some function settings are changed simultaneously with other functions being customized. Contact your Lexus dealer for further details.

Item	Function	Default setting	After customization
Wireless remote control (→P.22)	Wireless remote control function	ON	OFF
	Door unlock function	One push unlocks the driver's door, second push unlocks passenger's door	Ask your Lexus dealer
	Operation indicator buzzer	ON	OFF
	Operation indicator buzzer volume	Ask your Lexus dealer	
	Open door warning function (when locking the vehicle)	ON	OFF
	Automatic door locking function (if a door is not opened after being unlocked)	ON	OFF
		60 seconds	Ask your Lexus dealer
	Trunk unlock function	Push for about 1 second	Ask your Lexus dealer
	Lock/Unlock turn signal light confirmation	ON	OFF

Item	Function	Default setting	After customization
Door lock (→P.25)	Unlock function	One turn unlocks the driver's door, second turn unlocks passenger's door	Ask your Lexus dealer
	Speed-detecting automatic door lock function	OFF	ON
	Opening driver's door unlocks all doors	OFF	ON
	Shift the shift lever to "P" unlocks all doors	ON	OFF
	Shift the shift lever to position other than "P" locks all doors	ON	OFF
Power windows (→P.53)	Integrated door key operation	ON	OFF
	Wireless remote control integrated operation	Open	OFF
Alarm (→P.66)	Wireless remote control theft deterrent buzzer	ON	OFF
Automatic light control system (→P.129)	Ambient light sensor sensitivity	Ask your Lexus dealer	
	Time period before lights turn off	30 seconds	Ask your Lexus dealer
Windshield wiper (→P.133)	Automatic shift from LO speed to intermittent when the vehicle is stopped	ON	OFF
	Drip prevention function	ON	OFF
Steering column(→P.47)	Automatic tilt-away function	ON	OFF

6-2. Owner's customize

Item	Function	Default setting	After customization
Illumination (→P.183)	Time elapsed before lights turn off	15 seconds	7.5 seconds
			30 seconds
			0 seconds
	Operation after the Engine switch is turned OFF	ON	OFF
	Outer foot lights	15 seconds	7.5 seconds
			30 seconds
			0 seconds

6-2. Owner's customize

Initializing your Lexus

The following features should be initialized after certain maintenance is performed to ensure the system operates correctly.

Item	Maintenance performed	Reference
Front seats	Reconnected, replaced or recharged the battery.	P.33
Power windows	Reconnected, replaced or recharged the battery.	P.53
Engine oil replacement reminder	Changed engine oil.	P.228
Tire pressure warning system	When changing the tire inflation pressure by changing traveling speed or load weight, etc.	P. 243

6-2. Owner's customize